

Aikkon Est OÜ ceiling and wall elements maintenance and cleaning instructions.

Aikkon Est OÜ is not responsible or liable for incorrect maintenance and cleaning techniques, which may cause injuries to Aikkon Est OÜ's products and/or damage to the environment and to people.

- ✓ To varnished surfaces: use neutral detergent (pH 6-8) lightly wet wipes, dry with soft wipe.
Avoid abrasives, scrub sponges, mechanical scratching – it can damage the surface.



- ✓ Use soft duster to remove dust.



- ✓ Vacuum cleaner – use nozzle with long soft bristles.
Avoid standard nozzles with low bristles or hard surface – it can damage the surface.



- ✓ Steam cleaning – use low temperature steam and wide nozzle with soft cloth. This will disperse the steam without damaging the surface.
– Avoid using too hot steam, it will damage the varnish and acoustic fabric.

